Daintree Wireless Area Controller

(WAC60)



BEFORE YOU BEGIN

Read these instructions completely and carefully. Save these instructions for future use.

WARNING

Risk of electrical shock. Disconnect power before servicing or installing product. Install in accordance with National Electric Code and local codes.

The Daintree **WAC60 Wireless Area Controller (WAC)** is at the heart of the Daintree Networked wireless controls solution for smart buildings. It provides intelligent control across a large area. Using open and interoperable standards-based technology, the WAC60 communicates with wireless standards-compliant sensors, switches, lighting and HVAC control devices that are part of the Daintree Networked platform.

The WAC60 provides commissioning, control management and communication functions. It creates the mesh network, manages it, and applies the controls defined on the cloud hosted Daintree Controls Software (DCS) web application. After commissioning the system, all the schedules and control strategies are pushed to each WAC. WACs continue to execute the control strategies assigned to zones, and they run schedules even if they lose communication with DCS. DCS initiates device commissioning and houses the application used for ongoing management of the system.

The WAC60 is a low voltage DC powered device. It can be powered using the provided AC power adapter or using PoE (Power over Ethernet) supplied by a PoE adapter (not provided). The WAC60 communicates with the System Controller over Ethernet. An Ethernet hub or switch is required (not provided).

(1) Installation Process

The WAC60 must be installed in accordance with all local, state and national electrical codes and requirements.

Before mounting the WAC60 in its final location:

- **1.** Install and test lighting, control devices and wireless adapters per the instructions provided with the units.
- 2. Review the Where to Install the WAC60 section on the next page. Determine the location for the WAC. If power will be supplied by the AC power adapter, be sure there is a receptacle nearby. The Ethernet cable run from the Ethernet hub or PoE switch to the WAC location must be less than 300 feet.



 $\ensuremath{\textbf{Risk}}$ of injury. Wear safety glasses and gloves during installation and servicing.

- **3.** Once the location of the WAC60 has been determined, note its location and its IEEE address on the facility floor plan or relay schedule.
- 4. Make sure the WAC60 has been configured with appropriate network options as described in the facility's commissioning plan and associated worksheets.

2 Mounting and Connections

- 1. Remove the cover from the WAC to expose the wiring connectors.
- 2. Plug the Ethernet cable into the 🖧 🚺 port on the WAC.
- 3. Plug the power cable from either the AC power adapter or the PoE adapter into the ⊖- ⊕- ⊕ barrel connector on the WAC. When power is applied, the Status Indicator illuminates.
- **4.** Secure the power cable using the strain relief feature on the WAC60 base.
- 5. Mount the WAC60, using the four screw mounting holes on the WAC60 base.
- 6. Secure the Ethernet cable and the 12VDC power plug wire to a stationary point using a tie-wrap.
- 7. Reattach the cover to the WAC.
- 8. Use the Daintree web-based application to configure zones and devices. Wireless Area Controller (WAC60) Installation Instructions

Current 🗐

LED.com

© 2023 Current Lighting Solutions, LLC. All rights reserved. Information and specifications subject to change without notice. All values are design or typical values when measured under laboratory conditions.

(3) Where to Install the WAC60

Typically, the WAC60 is mounted high on a wall near the ceiling.

Ideally, the WAC60 is located in an area with good line of sight to nearby wireless devices in the Daintree wireless network.

- Do not locate the WAC60 inside a metal enclosure or where a large metal object completely obstructs the line of sight to all of the wireless network devices.
- Locate the WAC60 so that less than 300' of Ethernet cable is required to connect it to the Daintree system controller or Ethernet switch.
- Try to maintain at least 8'-10' distance from Wi-Fi access points.

(4) Wire Connections

Top view of WAC60 wiring connection area.

- The WAC60 must be able to communicate with at least one other AC-powered wireless device in the network.
- If the AC power adapter will be used to power the WAC60, make sure a power outlet is within reach of the plug-in adapter cord.
- If no power outlet is available, consider powering the WAC60 using a PoE adapter set for 12VDC (not provided).
- For outdoor installations, install in a non-metallic waterproof enclosure.



5 Strain Relief

Secure the 12VDC power plug wire to the strain relief tab on the side of the connector area near the barrel connector or in the wire channel on the back of the base. After mounting the WAC, provide external strain relief for the Ethernet cable and the 12VDC power plug wire by securing it to a stationary point using a tie-wrap.



(6) Mounting the WAC60





(7) Joining the Lighting Control Network

After the installation is complete, the WAC60 is ready to communicate with the Daintree web-based building management user interface.

For more information about configuring the lighting control network, see the instructions and online help provided with the Daintree user interface application

(8) Status Indicator

The status of the WAC displays through an opening in the cover. A green glow across the width of the opening indicates the unit is operating normally.

See the table in the **Troubleshooting** section if there are any other colors or patterns in the status indicator area.





Status Indicator Area Uniform green glow = power on and unit operating normally



© 2023 Current Lighting Solutions, LLC. All rights reserved. Information and specifications subject to change without notice. All values are design or typical values when measured under laboratory conditions.

(9) Troubleshooting

Status Indicator	Action Required	Description
Off	Apply power.	The WAC is not powered. Make sure the power adapter is plugged into the appropriate power source and inserted firmly into the 12VDC input on the WAC. Check to be sure plug adapters are connected properly and that circuit power is on.
Solid Green across entire light bar.	None. WAC is functioning.	Normal function. The device is powered and operating as expected.
Pulsing Green across entire light bar.	 If you are configuring the WAC using "link local" this is normal. When you are finished configuring the WAC web page, power cycle the WAC. If after the WAC restarts the light bar continues to pulse, the WAC cover may be pressing either Button A or B. 1. Remove the WAC cover and loosen the mounting screws. 2. Power cycle the WAC. 3. When the WAC finishes starting up (2-5 minutes), the light bar should be solid green all the way across. If the light bar starts pulsing green, contact technical support. If the light bar is solid green: 1. Put the cover off and loosen the screws more. 2. Power cycle the WAC. 3. When the WAC finishes starting up (2-5 minutes), the light bar is solid green: 1. Put the cover off and loosen the screws more. 2. Power cycle the WAC. 3. When the WAC finishes starting up (2-5 minutes), the light bar should be solid green all the way across. If so, attach the cover. If the light bar starts pulsing again, remove the cover, loosen the screws more and repeat the power cycle and cover replacement procedure. 4. When the light bar is solid green with the cover attached the problem is solved. If you are unable to stop the pulsing, contact technical support. 	The WAC is in "link local" mode, meaning that Button A or Button B on the WAC has been pressed as the WAC is powering on. This is typically done during the WAC configuration process, to provide local access to the WAC web page.
Green (solid) on both ends of the light bar. Center of the light bar is dark.	Wait. If a firmware upgrade is NOT in progress and the WAC remains in the mode for more than 10 minutes, power cycle the WAC. If this doesn't clear the problem, contact technical support.	The applications on the WAC are starting, or a firmware upgrade is in progress. If the WAC is starting up, it should be in this mode for less than 2 minutes. If a firmware upgrade is in progress it may be in this mode for 15-25 minutes, depending on the speed of the connection to the SC.
Green pulsing on both ends of the light bar. Center of the light bar is Orange.	Check Daintree application's web page.	 The WAC60 is not communicating with the SC. This could be because of the following reasons: The System Controller is not running. The WAC60 doesn't have Ethernet link. The WAC60 is not configured with the correct address for Daintree Controls Software
Solid Red in center of the light bar.	Contact technical support.	The WAC has had a hardware failure and must be replaced.

(10) Regulatory Information

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.

2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: 1. L'appareil ne doit pas produire de brouillage;

2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ٠ Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To satisfy FCC/ISED RF exposure requirements a separation distance of 20 cm or more must be maintained between the antenna of this device and persons during operation. Operation at closer than 20cm is not permitted.

Pour être conforme aux limites d'exposition aux ondes RF des norms FCC/ISED, une distance de separation d'au moins 20 cm doit être maintenue entre l'antenne de cet appareil et toute personne pendant son opération. Mettre en operation cet appareil a une distance plus rapprochée que 20 cm n'est pas permis.

Hereby, Current Lighting Solutions, LLC declares that the radio equipment type WAC60 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.LED.com

SPECIFICATIONS

Input Voltage:	12VDC 0.9A (max)
Power Connector:	2.1mm barrel connector
Input/Output Connectors:	10/100 Mbps Ethernet, 2 RJ45 ports USB (host): USB 2.0, 2 ports 1 Modbus/RS485 (via USB interface) Memory card: Micro SD card slot (USB 2.0 micro, not functional)
Capacity:	WAC60-DCS-Large: Up to 175 nodes WAC60-DCS-Small: Up to 60 nodes
Radio Properties:	USA/Canada: 2.4 GHz ISM band, 100mW (+20dBm) Europe: 2.4 GHz ISM band, 10mW (+10dBm)
Operating Environment:	Indoor, dry location (Outdoor: Environment non-metallic waterproof enclosure required) 32°F to 104°F (0°C to 40°C) with provided power adapter
Mounting:	Wall or ceiling surface
Dimensions:	9.4" H x 8.0" W x 1.2" D 238.1mm x 203.2mm x 30mm)
Distances, Maximum:	100' between wireless devices maximum (wireless range is clear line of sight) 300' of Ethernet cable between WAC and Ethernet switch or System Controller

PRODUCT CERTIFICATIONS



Contains: FCC ID: S4GEM358L IC: 8735AEM358L

CAN ICES-005 (B) / NMB-005 (B)

WAC60

CAUTION

RISK OF EXPOSURE IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSAL OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Questions:

Web: LED.com Phone: 1-866-855-8629 Email: daintree.support@currentlighting.com



CE

Current Lighting Solutions, LLC

25825 Science Park, Suite 400 Beachwood, OH 44122

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to Current.

LED.com

© 2023 Current Lighting Solutions, LLC, All rights reserved. Information and specifications subject to change without notice. All values are design or typical values when measured under laboratory conditions

Page 5 of 5 (Rev 06/13/23) DT117-Current-Daintree-Wireless-Area-Controller-WAC60-Install-Sheet