

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN.
IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 781-294-0100.

NOTES: BEFORE INSTALLING PLENUM COVERS, ALL SUPPORT RAILS MUST BE MOUNTED PER INSTRUCTION SHEET 510573.

LITECONTROL RECOMMENDS THAT THE FIXTURES ARE ATTACHED TO PLENUM COVERS PRIOR TO INSTALLATION: REFER TO INSTRUCTION SHEET 510258.

FIXTURE LENGTH MUST MATCH ITS PLENUM COVER LENGTH.

INSTRUCTIONS:

1. LIFT PLENUM COVER OVER EDGE OF SUPPORT RAILS.
ATTACH GUY WIRES (by others) FROM OVERHEAD CEILING STRUCTURE TO VERTICAL FORM ON FRONT (ROOM SIDE) OF PLENUM COVER.
2. THREAD IN LOCKING SCREWS AS SHOWN SO FIXTURE LOCKS IN SUPPORT RAIL.

