

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN.
IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 781-294-0100.

INSTRUCTIONS:

1. PRIOR TO WIRING FIXTURES: REMOVE COVER OF OUTLET BOX ON TOP SURFACE OF PLENUM COVER.
2. REMOVE A 7/8" KO IN BACK OF HOUSING CLOSEST TO THIS OUTLET BOX.
3. ATTACH FLEXIBLE CONDUIT (BY OTHERS) FROM THIS OUTLET BOX TO OUTLET BOX: BRING THE LABLED WIRES FROM FIXTURE THRU CONDUIT AND INTO OUTLET BOX. MAKE THE WIRING CONNECTIONS PER SCHEMATIC SHOWN IN THE EF PACK MANUFACTURER'S INSTRUCTIONS (SHIPPED WITH FIXTURE). GROUND HANDY BOX USING LEAD FROM FIXTURE PER CODE.
4. REPLACE OUTLET BOX COVER AFTER CONNECTIONS HAVE BEEN MADE.

