

TCAT

LED TWIN CONTEMPORARY ARCHITECTURAL TROFFER

INSTALLATION INSTRUCTIONS



STEP 1To avoid the possibility of electrical shock turn off power supply before installing or servicing this fixture.



STEP 2To remove the lens squeeze one end of the lens until you can reach under the center and pull the lens out.



STEP 3To remove the cover remove the 4 screws and squeeze the cover to release.



LED components are accessible.





LED TWIN CONTEMPORARY ARCHITECTURAL TROFFER

INSTALLATION INSTRUCTIONS (CONTINUED)



To reassemble reinstall the cover and replace the screws. Then install the lens by placing one edge into place and bending the other side to fit into place.



To reinstall lens, place one side of the lens against cover, squeeze lens and push up. Release lens and verify it is snug along housing.



STEP 6 Reapply power.