

PRECAUTIONS

- Read and understand all instructions before beginning installation.
- NOTICE: For installation by a licensed electrician in accordance with National and/or local Electrical Codes and the following instructions.
- Disconnect switch or a circuit breaker must be provided and marked as the disconnecting device.
- Disconnect switch / circuit breaker must be within reach of operator.
- CAUTION: RISK OF ELECTRICAL SHOCK. Turn power off at service panel before beginning installation. Never wire energized electrical components.
- CAUTION: USE COPPER CONDUCTOR ONLY
- Confirm device ratings are suitable for application prior to installation. Use of device in applications beyond its specified ratings or in applications other than its intended use may cause an unsafe condition and will void manufacturer's warranty.
- Use only approved materials and components (i.e. wire nuts, electrical box, etc.) as appropriate for installation
- NOTICE: Do not install if product appears to be damaged.

SAVE THESE INSTRUCTIONS!

If you have questions, call Current Lighting Control Service at: 1-877-584-2685 (LTG-CNTL) in the USA and Canada.

DESCRIPTION

The CLCCOVxx is a lockable cover for the Modular Lighting Control System.

The complete assembly consists of:

1. Tub (CLCTUBxx)
2. Interior (CLCINTxx)
3. Power Supply (CLCXFRxxx)
4. Cover (CLCCOVxx)


FEATURES

Each cover provides:

- Wiring Schedule directory card
- Hinged door
- Lock



CLCCOVxxS



CLCCOVxxSS4X, CLCCOVxxPS4
NEMA-4. NEMA-4X

CAUTION: Power to the relay panel should be off when installing or removing the cover.

Record the identification of the power supply circuit and the load controlled for each relay on the Wiring Schedule Card. Insert this card and the in the plastic sleeve affixed to the rear of the cover. Mount the CLCCOVxxS cover to the tub using ½" 10-24 screws provided. Mount the CLCCOVxxSS4X or CLCCOVxxPS4 cover using the hinge pins and Circlips provided as shown below

