

LED Emergency Exit (LUXE Series)



BEFORE YOU BEGIN

Read these instructions completely and carefully.

When using electrical equipment, basic safety precautions should always be followed including the following.

WARNING/AVERTISSEMENT

- · Do not use outdoors.
- Do not mount near gas or electric heaters.
- Equipment should be mounted in locations and at heights (MAX: 8ft) where it will not readily be subject to tampering by unauthorized personnel.
- The use of accessory equipment not authorized by the manufacturer may cause an unsafe condition.
- Do not use this equipment for other than its inteded purpose.
- Before wiring to power supply, turn off electricity at fuse or circuit breaker.
- Consult local building code for approved wiring and installation.
- · Installation and servicing of this equipment should be performed by qualified service personnel.

INSTALLER:

· See unit label for additional model specifications

WARNING:

• This product contains chemicals known to the State of California to cause cancer, birth defects and/or other reproductive harm. Thoroughly wash hands after installing, handling, cleaning, or otherwise touching this product.


Save These Instructions

Use only in the manner intended by the manufacturer. If you have any questions, contact the manufacturer.





Ceiling & End Mounting




- Connect input as shown in wiring diagram below and fasten canopy to J-box bracket.
- 2 Snap housing to canopy.
- If the exit has remote capacity, up to 4 remotes can be connected.
- Secure faceplate to housing and remove the proper arrow as required.


NOTICE: MUST WEAR GLOVE FOR ALL INSTALLATION PROCESSES

Wiring Diagram

EXIT SIGN



EXIT SIGN WITH REMOTE CAPACITY



WARNING: UNUSED WIRES MUST BE CAPPED USING ENCLOSED WIRE NUTS.



RECYCLING INFORMATION

All steel, aluminum, and thermoplastics parts are recyclable.
All cartons contain recycled materials.
Please recycle responsibly.

Specifications subject to change without notice.