


INSTALLATION INSTRUCTIONS

CATALOG NUMBER
SC4 / SC5
LC4 / LC5

CURVED ARMS

FIXTURE INSTALLATION

- 1) TURN OFF POWER.
- 2) ADJUST FIXTURE HEAD TO THE DESIRE POSITION AND SECURE WITH (2) BUTTON HEAD SCREWS.
- 3) MAKE WIRE CONNECTION FROM FIXTURE TO POLE.
(NOTE: ASSEMBLY MUST BE GROUNDED TO INCOMING EQUIPMENT GROUND SUPPLY).
- 4) SLIP FITTER OVER TOP OF POLE SECURE FITTER WITH (6) STAINLESS SET SCREWS.



LAMP INSTALLATION

- 5) TO INSTALL LAMP, INSERT FINGERS INTO SLOTS AND PULL BOTH LATCHES BACK SIMULTANEOUSLY.
- 6) OPEN THE BOTTOM HALF HOUSING AND INSTALL PROPER LAMP (BY OTHERS). CLOSE BOTTOM HALF HOUSING.

SERVICING BALLAST

- 7) LOOSEN BOTH SCREWS AND ALLOW BALLAST TRAY TO HANG DOWNWARD.
- 8) SERVICE BALLAST.
- 9) CLOSE BALLAST TRAY AND SCREW BACK ON TO THE UPPER HOUSING.