

Lighting Controls

DATE:	LOCATION:
TYPE:	PROJECT:
CATALOG #:	

WIR SERIES

WISCAPE® ENTERPRISE SOFTWARE



FEATURES

- Web-browser Graphical User Interface (GUI)
- Customizable dashboard with multi-site status
- Geographical mapping of devices on maps or layouts
- Intuitive management of devices, groups, scenarios and schedules
- Individual and multi-site energy reports with graphs
- Customizable security roles, users and rules
- Secure multi-concurrent user logins
- Customizable site/device alarms with SMS & email notifications



SPECIFICATIONS¹

HARDWARE OR VIRTUAL SERVER MINIMUM REQUIREMENTS (FOR UP TO 10,000 MODULES)

- 2 Core CPU (From at least year 2012)
- 2.5 GB of RAM
- 100 GB Hard Disk Storage
- Scalability Scenarios
 - Add 1 CPU core for every 20,000 modules over the minimum
 - Add 60 GB of storage for every 20,000 modules over the minimum
 - Add 1.5 GB of RAM for every 20,000 modules over the minimum

SOFTWARE REQUIREMENTS

- .NET Framework 4.5 (minimum)
- IIS 7 (minimum)
- Windows Server 2012 R2 (minimum)
- MySQL Server 5.6x (minimum)

NETWORK REQUIREMENTS

- Port UDP 8010 (in)
- Port TCP 8001 (in/out)
- Port TCP 3306 (out)
- Port TCP 3636 (in/out)
- Port TCP 3637 (in/out)
- Port TCP 2001 (out)

WARRANTY

- 5 year limited

Notes:

- 1 On-Premise Enterprise Server is a software only solution. Hardware/Virtual Server not provided.

Lighting Controls

WIR SERIES

WISCAPE® ENTERPRISE SOFTWARE

ORDERING GUIDE

Example: WIR-SS-ESRV

CATALOG #

Enterprise On-Premise Server Software

WIR-SS-ESRV	wiSCAPE On-Premise Enterprise Server (1 to 2499 nodes) - Installed on premise or cloud on system supplied by others (Windows® Server License Not Included)
WIR-SS-ESRV-2500	wiSCAPE On-Premise Enterprise Server (2500+ nodes) - Installed on premise or cloud on system supplied by others (Windows® Server License Not Included)
WIR-SS-ESRV-SETUP¹	wiSCAPE On-Premise Enterprise Server Installation via Remote Access
WIR-SS-ESRV-NLKEY^{1,2}	wiSCAPE On-Premise Enterprise Server Node License Key

Enterprise Hosted/SaaS Server Software³


WIR-HST-ESRV-SETUP	wiSCAPE Hosted Enterprise Server Setup - (Nodes not included)
WIR-HST-ESRV-NLKEY²	wiSCAPE Hosted Enterprise Server Node License Key
WIR-HST-ESRV-MAINT	wiSCAPE Hosted Enterprise Server Annual Maintenance Fee
WIR-HST-NODE-MAINT	wiSCAPE Hosted Node Annual Maintenance Fee (Per Node)

Notes:

- 1 Required with the purchase of either WIR-SS-ESRV or WIR-SS-ESRV-2500
- 2 License key required for each wiSCAPE module
- 3 Software as a Service (SaaS)

ADDITIONAL INFORMATION

System Deployment



Lighting Controls

WIR SERIES

WISCAPE® ENTERPRISE SOFTWARE

ADDITIONAL INFORMATION (CONTINUED)

Product Comparison

FEATURE	wISCAPE EXPRESS	wISCAPE ENTERPRISE
Create Groups, Command Scenarios, Schedules (Time-Based/Astronomical)	●	●
Name Devices	●	●
Assign Devices to Groups and Scenarios	●	●
Configure Device Parameters	●	●
Meter Devices	●	●
Individual & Group Device Control	●	●
Geographical Mapping of Devices on Maps or Plans	●	●
Windows® based Client Graphical User Interface (GUI)	●	●
Web-Browser based Client Graphical User Interface (GUI)		●
Secure Multi-Concurrent User Logins		●
Customizable Dashboard with Multi-Site Status		●
Dynamic Site Control		●
Customizable Security Roles, Users and Rules		●
Security User Logs		●
Individual & Multi-Site Energy Reports with Graphs		●
Customizable Site/Device Alarms with SMS & Email Notifications		●
Built-in Service Crew Maintenance Ticketing System		●