

NXSW2 Series

SMART WALL STATIONS

FEATURES

- Plug-and-play operation with NX Communication bus
- Device configuration through NX Lighting Controls Mobile App and NX Area Controller
- · Clean, unobtrusive & enduring design
- · Up to eight buttons in a single gang
- · Gang-able with other decorator type devices
- · Digitally addressable
- · Available in multiple colors
- · Five-year limited warranty



MOUNTING (cont)

*For installation with multi-gang Mud Rings please dry fit NXSW2 prior to installation to verify compatibility

Recommended multi-gang Mud Rings

 Raco 841
 Cooper TP496

 Raco 8778
 Cooper TP488

 Raco 780
 Steel City 52-C-00

 Raco 8781
 Orbit 42075

 Raco 8780SP
 Orbit 42058

 Cooper TP499
 Fraser Oaks MR-12E

ELECTRICAL INPUT

- Input Voltage: 12-24VDC supplied by NX Actuator (not included)
- Power Consumption: 15mA
- NX PBU: 2

PROGRAMMING INTERFACE

LOCATION:

PROJECT:

DATE:

TYPE:

CATALOG #:

- NX Lighting Controls Mobile App
- NX Area Controller (NXAC2) for Network Applications

OPERATING ENVIRONMENT

- · Rated for Indoor Use Only
- Operating temperature: 32°F to 104°F (0°C to 40°C)
- Relative humidity (non-condensing) 0% to 95%

CERTIFICATIONS

- cULus Listed
- Complies with FCC Part 15

WARRANTY

- 5 year limited warranty
- · See website for additional information

SPECIFICATIONS

CONSTRUCTION

- Housing: Rugged injection molded plastic, Polylac FR-ABS, (UL-94 5VA) flame class rating
- Color: White, Black, Gray, Ivory, Light Almond, Red
- Weight: 2.4oz (68g)
- Dimensions: 4.12" (104.65mm) H x 1.86" (47.24mm) W x 1.72" (43.4mm) D

MOUNTING

- Single-gang NEMA-style switch box (standard switch box - max mounting height: 48")
- Decorator-style wall plate sold separately

ORDERING GUIDE

| CATALOG # | | | | | | | NXSW2-4-WF |
|--|-----------------------|---|-------------|--|---|----------------|---|
| NXSW2 | | - | | | _ | | |
| NXSW2 | NX Smart Wall Station | | 1 2 3 4 | 1 Toggle Button 2 Toggle Button 3 Toggle Button 4 Toggle Button | | WH GY BK | White Gray Black ¹ |
| 1 - Made to Order Options; Consult Factory for Lead Times | | | 5 6 8 | 5 Toggle Button 6 Toggle Button 8 Toggle Button | | IV LA RD | lvory ¹ Light Almond ¹ Red ¹ |





DATE: LOCATION:

TYPE: PROJECT:

CATALOG #:

NXSW2 Series

SMART WALL STATIONS

ORDERING GUIDE

Cat5 Cable Ordering Guide


CATALOG #


| Model/Description | i |
|-------------------|---|
|-------------------|---|


| CAT5-3IN-OR-PLENUM | CAT5 Cable for NX SmartPORT™ Devices, Plenum Rated, 3in, Orange |
|---------------------|--|
| CAT5-3F-OR-PLENUM | CAT5 Cable for NX SmartPORT Devices, Plenum Rated, 3ft, Orange |
| CAT5-10F-OR-PLENUM | CAT5 Cable for NX SmartPORT Devices, Plenum Rated, 10ft, Orange |
| CAT5-25F-OR-PLENUM | CAT5 Cable for NX SmartPORT Devices, Plenum Rated, 25ft, Orange |
| CAT5-50F-OR-PLENUM | CAT5 Cable for NX SmartPORT Devices, Plenum Rated, 50ft, Orange |
| CAT5-100F-OR-PLENUM | CAT5 Cable for NX SmartPORT Devices, Plenum Rated, 100ft, Orange |



DIMENSIONS









NXSW2 Series

DATE: TYPE: PROJECT: CATALOG #:

LOCATION:

ADDITIONAL INFORMATION

Setup and Configuration

Models: NXSW2-1, NXSW2-2, NXSW2-3, NXSW2-4, NXSW2-5, NXSW2-6, NXSW2-8

As shipped, all buttons on these stations are configured as Toggle type (press for ON/press for OFF) with LED status. The buttons can be configured for alternate operation using the NX Lighting Controls App.


| BUTTON TYPES | | | | |
|----------------------|---|--|--|--|
| Toggle | Sends group ON/group OFF, factory configuration | | | |
| ON | Sends group ON to full level, relay control is optional | | | |
| OFF | Sends group OFF to minimum level, relay control is optional | | | |
| Single Button ON/OFF | Sends group ON to level/group OFF to level, relay control is optional | | | |
| Raise | Raise dimming level | | | |
| Lower | Lower dimming level | | | |
| Preset | Activate a preset scene, 1 – 16 | | | |
| Timed ON | Sends ON with selectable timeout to OFF | | | |
| CCT ON | Sends ON, level, and sets color | | | |
| Disabled | Disables the button | | | |
| CCT Raise | Increase color temperature | | | |
| CCT Lower | Lower color temperature | | | |
| Partition | Sends room combine/separate message | | | |
| ON/Raise/Lower/OFF | Touch for ON, hold for raise/lower, touch for OFF | | | |
| Emergency Override | Sends Fire Emergency Command (Default is Maintained) | | | |
| Demand Response | Sends Demand Response Level for the Zone (1-10) | | | |
| ON/Raise | Touch for ON, hold to raise dimming level | | | |
| Lower/OFF | Touch for OFF, hold to lower dimming level | | | |















NXSW2-1

NXSW2-2

NXSW2-3

NXSW2-4

NXSW2-5

NXSW2-6

NXSW2-8




NXSW2 Series

SMART WALL STATIONS

ADDITIONAL INFORMATION (CONTINUED)

Wiring Diagrams



Dimming V Violet NX Room Controller NX Room Controller No NX Room Controller NX Room Cont

LOCATION:


PROJECT:

DATE:

CATALOG #:

NXSW2 Wall Station with NX Room Controller

Multiple NXSW2 Wall Stations daisy chained with NX Room Controller



Multiple NXSW2 Wall Stations daisy chained with NX Enabled Luminaire

