


DATE: LOCATION:

TYPE: PROJECT:

CATALOG #:

## **RETA - Four Fixture Round Tenon Adapter**

TENON ADAPTERS ACCESSORY



## **Mounting Notes:**

- 1. Engage set-screws to adapter half way in.
- 2. Slip adapter to pole tenon, then tighten set-screws.
- 3. Mark tenon using hole "A" as guide.
- 4. Remove adapter from tenon.
- 5. Drill tenon thru walls using 7/16" (.437") diameter drill bit.
- 6. Install adapter back to tenon securing it with 3/8-16 thru bolt, lockwasher, and hex nut.
- 7. Tighten set-screws.
- 8. The adapter is now ready for fixture installation.
- 9. Install 7/16 plugs into unused holes.

## Shipping Package Contents:

RETA Tenon Adapter (1)

Top Cover (1)

3/8-16 Bolt (1)

3/8-16 Set Screw (4)

3/8 Split Washer (1)

3/8-16 Nut (1)

7/16 Plug (11)

Material: Aluminum Finish: Powder Paint

Weight: 20 lbs

**EPA:** 0.2 ft<sup>2</sup>

