

NOTES:

- 1. Under normal conditions, the emergency load is controlled by the NX Room Controller.
- 2. During the loss of normal power, the emergency dimmed load will go to 100% output.
- 2.1. When normal power is restored the dimmed level will be based on the Room Controller Power On settings.

ALCR1277_NXRC-1RD_No Normal Load



www.Hubbell-Automation.com

Greenville, SC 29607

HUBBELL Control Solutions

Main Switchboard: (864) 678-1000 Technical Service: (800) 888-8006

THIS DOCUMENT AND SPECIFICATIONS
DESCRIBED WITHIN ARE THE
EXCLUSIVE PROPERTY OF
HUBBELL CONTROL SOLUTIONS ISSUED
IN THE STRICTEST CONFIDENCE, AND
SHALL NOT BE REPRODUCED,
COPIED OR USED WITHOUT PRIOR
WRITTEN PERMISSION.

RAWN BY: DATE: 11/07/2019

HCS