


NOTES:

1. Under normal conditions, the emergency load is controlled by the NX Room Controller.
2. During the loss of normal power, the emergency dimmed load will go to 100% output.
 - 2.1. When normal power is restored the dimmed level will be based on the Room Controller Power On settings.
3. During the loss of normal power, emergency dimmed loads will go to 100% output.
 - 3.1. When normal power is restored the dimmed level will be based on the Room Controller Power On settings.

TITLE:		ALCR1277_NXRC-2RD_2 Zones	
 HUBBELL Control Solutions	THIS DOCUMENT AND SPECIFICATIONS DESCRIBED WITHIN ARE THE EXCLUSIVE PROPERTY OF HUBBELL CONTROL SOLUTIONS ISSUED IN THE STRICTEST CONFIDENCE, AND SHALL NOT BE REPRODUCED, COPIED OR USED WITHOUT PRIOR WRITTEN PERMISSION.		DRAWN BY: AJ
			DATE: 11/07/2019
701 Millennium Blvd. Greenville, SC 29607 www.Hubbell-Automation.com		Main Switchboard: (864) 678-1000 Technical Service: (800) 888-8006	
		HCS	