

NOTE:

Disconnect power prior to installation.

NXDCI WITH NXFM-I AND NX SM OCCUPANCY SENSOR / 1 DIMMING DRIVER



Greenville, SC 29607

www.Hubbell-Automation.con

Main Switchboard: (864) 678-1000 Technical Service: (800) 888-8006

THIS DOCUMENT AND SPECIFICATIONS DESCRIBED WITHIN ARE THE EXCLUSIVE PROPERTY OF JBBELL CONTROL SOLUTIONS ISSUED IN THE STRICTEST CONFIDENCE, AND SHALL NOT BE REPRODUCED, COPIED OR USED WITHOUT PRIOR WRITTEN PERMISSION.

DATE: 09/12/2017

NX