



NOTES:

- 1. Disconnect Line Voltage prior to installation or servicing the Room Controllers.
- 2. An NXRC-UL924 Room Controller must be connected to a standard NX Room Controller Smart Port. Limit one NX UL924 Room Controller per Smart Port.
- 3. No Input Control Device should be connected to the NXRC-UL924 Device.
- 4. During Normal conditions both Room Controllers will function together and per programming.
- 4.1. When Normal Power is lost, the NXRC-UL924 Controller will default to non-controlled ON state, until normal power is restored.

NXRC-UL924-UNV, NXRC-2R, OMNI, SW-ORLO



HUBBELL Control Solutions

701 Millennium Blvd. Main Switchboard: (864) 678 Greenville, SC 29607 Technical Service: (800) 888 www.Hubbell-Automation.com THIS DOCUMENT AND SPECIFICATIONS
DESCRIBED WITHIN ARE THE
EXCLUSIVE PROPERTY OF
HUBBELL CONTROL SOLUTIONS ISSUED
IN THE STRICTEST CONFIDENCE, AND
SHALL NOT BE REPRODUCED,
COPIED OR USED WITHOUT PRIOR
WRITTEN PERMISSION.

AJ 11/08/2019

Main Switchboard: (864) 678-1000 SHALL NOT Technical Service: (800) 888-8006 COPIED OR U

HCS