



NOTE:

Disconnect power prior to installation.

TITLE: NXRМ-H BEFORE THE NXSM OCCUPANCY SENSOR USING THE NXFM-O, CTC DRIVER



HUBBELL Control Solutions

701 Millennium Blvd.
Greenville, SC 29607
www.Hubbell-Automation.com

Main Switchboard: (864) 678-1000
Technical Service: (800) 888-8006

THIS DOCUMENT AND SPECIFICATIONS DESCRIBED WITHIN ARE THE EXCLUSIVE PROPERTY OF HUBBELL CONTROL SOLUTIONS ISSUED IN THE STRICTEST CONFIDENCE, AND SHALL NOT BE REPRODUCED, COPIED OR USED WITHOUT PRIOR WRITTEN PERMISSION.

DRAWN BY: AJ DATE: 09/13/2017

PRODUCT FAMILY:

NX