

NOTE:

Disconnect power prior to installation.

NXSMP-LMI USING THE NXFM-I AND CTC DRIVER



701 Millennium Blvd. Main Switchboard: (864) 678-1000
Greenville, SC 29607 Technical Service: (800) 888-8006
www.Hubbell-Automation.com

THIS DOCUMENT AND SPECIFICATIONS
DESCRIBED WITHIN ARE THE
EXCLUSIVE PROPERTY OF
HUBBELL CONTROL SOLUTIONS ISSUED
IN THE STRICTEST CONFIDENCE, AND
SHALL NOT BE REPRODUCED,
COPIED OR USED WITHOUT PRIOR
WRITTEN PERMISSION.

AS DRAWN BY: DATE: 09/13/2017
PRODUCT FAMILY:

