

## NOTE:

Disconnect power prior to installation.

TITLE:

Greenville, SC 29607

www.Hubbell-Automation.com

## NXSMP-LMI, NXFM-LV AND 1-DIMMING DRIVER



Main Switchboard: (864) 678-1000 Technical Service: (800) 888-8006

THIS DOCUMENT AND SPECIFICATIONS
DESCRIBED WITHIN ARE THE
EXCLUSIVE PROPERTY OF
HUBBELL CONTROL SOLUTIONS ISSUED
IN THE STRICTEST CONFIDENCE, AND
SHALL NOT BE REPRODUCED,
COPIED OR USED WITHOUT PRIOR
WRITTEN PERMISSION.

S DRAWN BY: DATE: 09/13/2017

NX