



**NOTE:**

Disconnect power prior to installation.

TITLE: <b>NXSMP-LMI USING THE NXFM-LV AND CTC DRIVER</b>	
 <b>HUBBELL</b> <b>Control Solutions</b>	THIS DOCUMENT AND SPECIFICATIONS DESCRIBED WITHIN ARE THE EXCLUSIVE PROPERTY OF HUBBELL CONTROL SOLUTIONS ISSUED IN THE STRICTEST CONFIDENCE, AND SHALL NOT BE REPRODUCED, COPIED OR USED WITHOUT PRIOR WRITTEN PERMISSION.
	DRAWN BY: <b>AJ</b> DATE: <b>09/13/2017</b> PRODUCT FAMILY: <b>NX</b>
701 Millennium Blvd. Greenville, SC 29607 www.Hubbell-Automation.com	Main Switchboard: (864) 678-1000 Technical Service: (800) 888-8006