


**NOTE:**

Disconnect power prior to installation.

TITLE: <b>NXSMPLMO USING THE NXFMLV AND CTC DRIVER</b>	
 <b>HUBBELL</b> <b>Control Solutions</b>	THIS DOCUMENT AND SPECIFICATIONS DESCRIBED WITHIN ARE THE EXCLUSIVE PROPERTY OF HUBBELL CONTROL SOLUTIONS ISSUED IN THE STRICTEST CONFIDENCE, AND SHALL NOT BE REPRODUCED, COPIED OR USED WITHOUT PRIOR WRITTEN PERMISSION.
	DRAWN BY: <b>AJ</b>
701 Millennium Blvd. Greenville, SC 29607 <a href="http://www.Hubbell-Automation.com">www.Hubbell-Automation.com</a>	Main Switchboard: (864) 678-1000 Technical Service: (800) 888-8006
<b>PRODUCT FAMILY:</b> <span style="font-size: 2em; font-weight: bold;">NX</span>	