

NOTE:

Disconnect power prior to installation.

Greenville, SC 29607

NXSMP-SMI USING THE NXFM-O AND CTC DRIVER



Main Switchboard: (864) 678-1000 Technical Service: (800) 888-8006 www.Hubbell-Automation.com

THIS DOCUMENT AND SPECIFICATIONS DESCRIBED WITHIN ARE THE EXCLUSIVE PROPERTY OF JBBELL CONTROL SOLUTIONS ISSUED IN THE STRICTEST CONFIDENCE, AND SHALL NOT BE REPRODUCED, COPIED OR USED WITHOUT PRIOR WRITTEN PERMISSION

DATE: 09/13/2017

