

Square Transit LED Signal

LS6-WFA3-01B-5



BEFORE YOU BEGIN

Read these instructions completely and carefully. If you prefer to have this Installation Instructions document in other languages, visit our official website at: www.LED.com/transportation

⚠ WARNING / AVERTISSEMENT

RISK OF ELECTRIC SHOCK

Disconnect Before Servicing or installing product. The LED module must be installed into a signal head with adequate ingress protection for the location (protection from the weather).

RISQUES DE DÉCHARGES ÉLECTRIQUES

Couper l'alimentation avant le dépannage ou avant l'installation du produit. Le module DEL doit être installé dans une tête de signal avec une protection adéquate d'entrée pour l'emplacement (protection contre les intempéries).

Operating Specifications

	12V Module Only
Input voltage range	10V to 12V

Prepare Electrical Wiring



Electrical Requirements

- Follow all National Electric Codes (NEC) and local codes.

Important Information

- LED module fits into most standard railway signal heads.
- LED module is self-contained – no assembly is required.
- This product is intended solely for the use of rail signaling and is not intended for use in any other applications
- As per AREMA guidelines, provisions should be made for periodic functional checks of safety devices and features incorporated into this product.
- Current recommends that primary and secondary surge protection be added additional to the tertiary surge protection in the lamp. Arema 11.3.3
- This product is intended solely for the use of rail signaling and is not intended for use in any other application.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAN ICES-005 (A)/NMB-005(A)

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Installation Steps

- ① Existing signal head in the field: Remove lens and incandescent bulb assembly from housing.
- ② Existing in-line rheostat in the field: Set rheostat (variable resistor) to zero "0" or remove completely.
- ③ Voltage settings: Check the label on the back of the LED module to ensure the voltage corresponds to the system voltage. The recommended voltage at the signal head is 10 to 12V.
- ④ Wiring: The module consists of one white wire and one colored wire. There is no significance to the different colors with respect to the input voltage polarity.
- ⑤ Insertion of LED module into signal head: Insert the LED module into lens slot and tighten metal tabs, or insert LED module into the external ring holder.

