


INSTALLATION INSTRUCTIONS

MOUNTING TYPE: DRYWALL OR GRID

SUPPORT RAIL INSTALLATION

SUPPORT RAIL(S) MUST BE INSTALLED PRIOR TO INSTALLATION OF FIXTURE(S).



NOTE: LAST SECTION(S) OF SUPPORT RAILS MAY NEED TO BE FIELD CUT.

TO ENSURE SUPPORT RAILS MAINTAIN ALIGNMENT, **INSERT SPLINE KEYS BETWEEN RAIL ENDS AS EACH** LENGTH IS ADDED. SHIM BEHIND SUPPORT RAILS WHEN NECESSARY TO FORM A CONTINUOUS STRAIGHT RAIL. BUTT RAIL TO RAIL CORNERS THEN CONTINUE ONTO FIXTURE INSTALLATION.

LITECONTROL	_
-------------	---

litecontrol.com

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCT YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT. PLEASE CALL LITECONTROL ENGINEER

DRYWALL SUPPORT RAIL				
HEIGHT				
DIMENSION "C" (support rail to top of ceiling)				
	2L	3L/4L/6L		
WS0	3/4"	2 15/16"		
WS2	3 1/4"	5"		
WS3	4 1/4"	6"		
WS4	5 1/4"	7"		

TIONS CONTAINED HEREIN. IF	DRAWING: 510690	
RING AT 781-294-0100	REV:7	DATE: 03/20/2025


INSTALLATION INSTRUCTIONS

FIXTURE SERIES: MOD PERIMETER / Wall/Slot[®]

MOUNTING TYPE: DRYWALL OR GRID

FIXTURE INSTALLATION

!!! FIXTURE(S) MUST BE INSTALLED PRIOR TO INSTALLATION OF CEILING. **!!!**



LITECONTROL

litecontrol.com

DO NOT MODIFY OR ALTER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUC YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT. PLEASE CALL LITECONTROL ENGINEE

TIONS CONTAINED HEREIN. IF	DRAWING: 510690	
RING AT 781-294-0100	REV:7	DATE: 03/20/2025

INDIVIDUAL UNITS CANNOT BE JOINED IN FIELD TO CREATE RUNS.


REMOVE REFLECTOR ASSEMBLY BY REMOVING (2) #8

7

MOUNTING TYPE: DRYWALL OR GRID

CEILING INSTALLATION GUIDLINES

!!! FIXTURE(S) MUST BE INSTALLED PRIOR TO INSTALLATION OF CEILING. **!!!**




LITECONTROL

litecontrol.com


DO NOT MODIFY OR ALTHER THIS PRODUCT IN ANY WAY, OR INSTALL IN ANY FASHION WHICH IS CONTRARY TO THE INSTRUCTIONS CONTAINED HEREIN. IF YOU HAVE ANY QUESTIONS REGARDING THIS PRODUCT OR THE INSTALLATION OF IT, PLEASE CALL LITECONTROL ENGINEERING AT 781-294-0100

PAGE: 4 OF 6

DRAWING: 510690 REV:7 DATE: 03/20/2025



L OR GRID	PAGE: 5 OF 6	
LENS REMOVA	AL	
	FIXTURE	
PULL LENS DOWN TO DISENGAGE LENS FROM		
PLENUM SHIELD REMOVAL		
HOUSING	SCREWS	
	PLENUM SHIELD	
E PLENUM SHIELD BY REMOVING (#8) SCREWS AS		
CTIONS CONTAINED HEREIN.	DRAWING: 510690	
ERING AT 781-294-0100	REV:7 DATE: 03/20/2025	



TIONS CONTAINED HEREIN. IF	DRAWING: 510690	
RING AT 781-294-0100	REV:7	DATE: 03/20/2025