

HA13S - Side Pole S-Shaped Down Cast Arm Installation Instructions


⚠ WARNING: Fixtures must be grounded in accordance with local codes or the National Electrical Code. Failure to do so may result in serious personal injury.

MAINTENANCE: A regularly scheduled maintenance program must be established to insure paint coating is intact, corrosion or structural damage has not occurred, and all mounting arms, rods, nuts, and bolts are tight. Failure to do so could lead to damage or serious personal injury.


KEEP THIS SHEET FOR FUTURE REFERENCE.

- Tools Required:** Flat Head Screwdriver Torque Wrench 1/8" Hex Wrench
 9/16" 6- or 12- Point Deep (2" min.) Socket 12" (min.) Long Socket Extension


⚠ Make certain electrical supply is OFF before starting fixture installation.




1. Thread fixture wires through S-Shaped Down Cast Arm and out access cover.



2. Install the fixturebase to down cast arm. **Important! Keep wires tight when attaching fixture to arm to avoid pinching wires.** See fixture installation instructions for fixture attachment.



3. Lay pole horizontal on padded supports to protect finish. Pull wires through pole & out the top. Tie-wrap wires to pole backing plate. Tie wires in a knot or back loop through tie-wrap. Wire leads need to extend 12" beyond the hand hole.



4. Attach down cast arm to pole. Tighten to 20 ft.-lbs.



5. Push wires into pole and out pole hand hole. Secure wire with the cable tie provided. Make wire connections observing polarity, i.e.; green-to-ground, white-to-common and black-to-voltage. Install arm access cover and secure with screws.

For warranty see: currentlighting.com/kimlighting