


NOTES:

1. Under normal conditions, both emergency and normal loads are controlled by the NX Room Controller.
2. Upon loss of normal power:
 - 2.1. The normal load will de-energize and stay off until normal power is restored.
 - 2.2. The emergency load will turn on and stay on until normal power is restored. No control functions are available until normal power is restored.
3. During the loss of normal power, emergency dimmed loads will go to 100% output.
 - 3.1. When normal power is restored the dimmed level will be based on the Room Controller Power On settings.

TITLE:		ALCR1277_NXRC-1RD_Split Control	
 HUBBELL Control Solutions	THIS DOCUMENT AND SPECIFICATIONS DESCRIBED WITHIN ARE THE EXCLUSIVE PROPERTY OF HUBBELL CONTROL SOLUTIONS ISSUED IN THE STRICTEST CONFIDENCE, AND SHALL NOT BE REPRODUCED, COPIED OR USED WITHOUT PRIOR WRITTEN PERMISSION.		DRAWN BY: AJ
	701 Millennium Blvd. Greenville, SC 29607 www.Hubbell-Automation.com		Main Switchboard: (864) 678-1000 Technical Service: (800) 888-8006
			HCS